

Mounting protocol of mandibular coil springs with rods PUL1 system

The small diameter end of mandibular coil spring must be imbedded into the frame to avoid breakage.



To imbed the coil spring, mill a hole with a round 2mm bur.



Once imbedded, maintain the coil spring slightly compressed and block by bending the support ball clasp in this position.



2nd Option: mounting PUL1 without coil springs

For mounting without coil springs, block the lower rod system by positioning it in vertical right angle, it will give the necessary clearance for proper mounting.

